

The **PX** Series

Engineered for professional performance



The **PX** Series



ENGINEERED FOR PROFESSIONAL PERFORMANCE

Pramac introduces the PX series, engineered and designed for a professional performance. Ready to move where power is needed, and configured with a strong and compact frame with integrated handle and wheels, that allows to transport it easily. All parts of the PX generators have been thought to give a long lasting professional generator, with a low noise emission to guarantee the best working conditions. The control panel has been configured to put at your disposal the right outputs, controls and information. Its digital display shows, with the touch of a button, working hours, Hertz and volts. The PX Series gives you the best power for professional tools.

TECHNICAL FEATURES

- Compliant to the Noise level in Europe
- Control panel (Hourmeter / Voltmeter / Frequency meter)
- Steel tank
- Roll cage design
- Folding handle with foam
- No assembly required
- Wheel kit assembled so it is easy to move
- Pramac after sales service guaranteed

COMPACT, EFFICIENT, DURABLE



The **PX** generators are ready to use. They are supplied with a transportation kit already assembled, no tools required. You just have to add gas and oil!



PX generators are equipped with an Automatic Voltage Regulation (AVR) as standard. It allows generator to produce clean power. The AVR is an electronic regulation system which stabilizes the voltage output from the generator. The quality of this output allows connection of most devices to the generator.



The Quick start slide out Instruction Guide is located just below the control panel of the generator. It is extremely useful to learn how to start your **PX** generator safely.



The control panel, carbon designed, is provided with CE sockets to get the maximum output and it guarantees thermal protection. In order to better control the performance of the generators all the **PX** are also equipped with a 3 function digital screen: hour meter, volt meter, frequency meter.

How to select the right portable generators?

- Identify all the items you want to power at the same time.
- Total the Watts for all the items (Amps x Volts = Watts).
- Note that electric engines require substantially more Watts (2 to 3 times more) for starting.
- Choose a Pramac generator that exceeds the total starting Watts.

PX SERIES PETROL

GENERATING SET	PX 4000	PX 5000	PX 8000	PX 8000
	SINGLE PHASE			THREE PHASE
POWER THREE PHASE				
POWER LTP	-	-	-	4,8 / 6,0
POWER COP	-	-	-	4,0 / 5,0
POWER SINGLE PHASE				
POWER LTP	2,7 / 3,0	3,6 / 4,0	5,4 / 6,0	1,8 / 2,0
POWER COP	2,3 / 2,5	2,7 / 3,0	4,5 / 5,0	1,3 / 1,5
POWER SPECIFICATIONS				
VOLTAGE	230	230	230	400 / 230
FREQUENCY	50	50	50	50
ENGINE				
BRAND	Pramac OHV	Pramac OHV	Pramac OHV	Pramac OHV
MODEL	AP170F	AP188F	AP190F	AP190F
FUEL	Petrol	Petrol	Petrol	Petrol
DISPLACEMENT	208	389	420	420
STARTING SYSTEM	Recoil	Recoil	Electric (+ Recoil)	Electric (+ Recoil)
CONSUMPTION				
FUEL CONSUMPTION at 75% of load	0,96	1,44	2	2,06
FUEL TANK CAPACITY	18,5	25,5	25,5	25,5
RUNNING TIME at 75% of load	19,27	17,71	12,75	12,38
NOISE EMISSION				
NOISE PRESSURE LEVEL at 7 mt	68	69	69	69
GUARANTEED SOUND POWER LEVEL	96	97	97	97
DIMENSION AND WEIGHT				
LENGTH	600	727	727	727
WIDTH	439	515	515	515
HEIGHT	588	670	670	670
WEIGHT (DRY)	53	79	94	97
SOCKET TYPE				
	2 x 230V SCHUKO	2 x 230V SCHUKO	1 x 230V SCHUKO	1 x 230V SCHUKO
		1 x 230V CEE 16A	1 x 230V CEE 16A	1 x 230V CEE 16A
			1 x 230V CEE 32A	1 x 400V CEE 16A
ALTERNATOR AND SOCKET PROTECTION				
ALTERNATOR PROTECTION	IP 23	IP 23	IP 23	IP 23
SOCKET PROTECTION	IP 54	IP 44	IP 44	IP 44

Power LTP = Maximus Power - Power COP = Continuous Power - Other configurations and detailed specifications are available on www.pramac.com

PX Series: the range



Distributed by

ENERGY GENERATION



BEING COMPETITIVE IS OUR DNA

From the Pramac Racing Team to the production of material handling equipment and power generating sets,

Pramac is always ahead of the competition.

Quality, innovation and reliability are our key factors to satisfy customers.

BE OUR PARTNER, JOIN THE ENERGY GENERATION!



PR INDUSTRIAL S.R.L.

Località Il Piano, 53031 Casole d'Elsa (SI) Italy / Tel +39 0577 9651, Fax +39 0577 949076 / info.it@pramac.com / www.pramac.com
Worldwide Service & Parts Online Center: www.pramacparts.com